
Dye & Stain Application Instructions For Signature Bespoke Produced Floors Only

Your Touch-Up Kit Includes:

1. COLOR DYE – Water-based pre-stain treatment (color pigment)
 2. STAIN MIX – Custom oil-based stain blend
 3. CLEAR POLYX OIL – Penetrating oil-based surface finish
-

IMPORTANT BEFORE YOU BEGIN:

- Always test products on an inconspicuous area first.
 - Work in a well-ventilated area.
 - Wear gloves and follow all safety precautions.
 - Read all the instructions before starting.
-

STEP 1: DYE APPLICATION (*Water-Based Pre-Stain Pigment*)

- Shake and mix well before use.
 - Pour dye into a clean tray.
 - Use a white buffing pad provided to apply the dye with the grain of the wood.
 - Apply evenly — do not wipe off after application.
 - Allow 2–3 hours to dry and soak into the wood completely.
-

STEP 2: STAIN MIX APPLICATION (*Oil-Based Custom Stain*)

- Mix thoroughly before use.
 - Pour stain into a tray.
 - Apply a generous coat using a carpet applicator or brush.
 - Rub in the stain using the included white buffing pad.
 - Use light, circular motions — avoid excessive pressure:
 - Gentle rubbing deepens the color
 - Heavy rubbing will lighten the color
 - Once desired color tone is achieved, wipe off stain completely.
 - Allow to dry for 8-10 hours (overnight) before proceeding.
-

STEP 3: CLEAR POLYX OIL APPLICATION (*Oil-Based Finish*)

- Stir well before use.
 - Apply a small amount of Polyx Oil directly onto a clean white buffing pad.
 - Rub the oil into the surface using gentle circular motions.
 - Wipe off excess with a new clean white pad.
 - Let dry for 8–10 hours between coats.
 - Apply 2-3 coats total for best results.
-

CRITICAL NOTICE:

Do not apply Polyx Oil until stain is fully dry.

Applying oil on a wet or tacky stain will cause it to dissolve and smear the color.





handcrafted european wood floors

OUR HARDWOOD FLOORS

SAFETY WARNING – FIRE HAZARD:

Cloths, pads, or rags soaked with oil-based stains or finishes can spontaneously combust if not handled and disposed of properly.

TO PREVENT FIRE:

After use, rinse the white pad and all stain-contaminated applicators with clean water.

Dispose of all used rags, pads, and materials — flammable and non-flammable — in accordance with local and state regulations.

Never leave oil-soaked materials balled up or unattended.

IMPORTANT TIPS:

Always test touch-up materials on a hidden area first.


Avoid overapplying filler or stain — thin layers blend more naturally.

For larger damage or unclear situations, contact Signature Innovations for professional assessment.

Do not use polyurethane or water-based topcoats unless specified by us — our finish systems are oil-modified and require compatible products.

Need Help or Have Questions?

We're here to help.

 Call Us: 866.554.4252

 Email: sales@signaturehardwoods.com

 Visit: www.signatureinnovations.com/downloads

Here you'll find additional product specifications and downloadable guidelines.



Showroom & Design Studio | 1171 Landmeier Road, Elk Grove Village, IL 60007 | 847.758.9600 | toll free 866.554.4252

www.signatureinnovations.com | sales@signaturehardwoods.com